


# INSTALLATION INSTRUCTION 1700

## Parts List


Please check the parts in the package in comparison with the following list, make sure all of the parts are in the package. Never use defective parts, never replace part with different specification.



## 3. Installation and operation instructions


Note: please read the instructions carefully before installation!

### STEP-1




Step 1:  
Tighten the four wheels through the washer to the base.

### STEP-2




Step 2:  
Insert the tubes into the base and tighten the screw.

### STEP-3




Step 3:  
Assemble two panels.

### STEP-4




Step 4:  
Install the DVD tray.

STEP-5




Step 5:  
Install the TV plate.

STEP-7




Step 7:  
Hang the TV onto the TV plate.

STEP-6



Step 6:  
Install the TV bracket onto the back  
of the TV.

STEP-8



Step 8:  
Install the camera assembly.  
The camera assembly is installed behind the TV plate.