

# INSTALLATION INSTRUCTION

## KM-1800

### Parts List


Please check the parts in the package in comparison with the following list, make sure all of the parts are in the package. Never use defective parts; never replace part with different specification.

A		1	F		10mm-4
		8mm-1	G		M8x25-4
B		M6x60-2	H		M6x25-4
		M5x10-4	I		M8x70-4
C		M6x10-2	J		M8x70-4
D		M8x12mm-20	K		M8x40-8
E		8mm-8			

### 3. Installation and operation instructions


Note: please read the instructions carefully before installation!

#### STEP-1




Step 1:  
Tighten the four wheels through the washer to the base.

#### STEP-2




Step 2:  
Insert the tubes into the base and tighten the screw.

#### STEP-3




Step 3:  
Assemble two panels.

#### STEP-4




Step 4:  
Install the DVD tray.

#### STEP-5




Step 5:  
Install the TV plate.

#### STEP-7




Step 7:  
Hang the TV onto the TV plate.

#### STEP-6



Step 6:  
Install the TV bracket onto the back of the TV.

#### STEP-8



Step 8:  
Install the camera assembly.  
The camera assembly is installed behind the TV plate.