



# 液晶电视桌面架安装说明

## TV stand installation instructions



The gasket positions of E and F are the same. Please select the same gasket according to your requirements.

A、B、C三款螺丝使用位置，  
请按需求使用螺丝即可

